# BUT A B L E S MARTdesks<sup>®</sup> WWW.smartdesks.com 800-770-7042




A grouping is arranged, then the casters are locked to keep the arrangement stable. Plako<sup>®</sup> interlocking plates are fixed to the underside to provide additional connected stability to the arrangement.

Three legs are attached to each iGroup Table Element, using 8 hex head/phillips drive 1/4-20 bolts, provided for each leg.

Mesh modesty panels provide wire management with hook/loop closures. They hang from two hooks which are attached with screws.




Legs may be fixed height or adjustable height. They install the same way. A SnapChase<sup>™</sup> wire management sleeve is shown installed on a rear leg. iGroup<sup>®</sup> Tables are shaped in right triangles with a curve on the user side. They are produced to order with this curve on the right or left side, usually in sets, to produce mirror-image shapes or radial shapes.



### Install three legs


Use a Phillips #2 drive or 3/8" hex drive to install eight 1/2" bolts for each leg.




## Install Plako joining plates

Plako clips are used to hold the igroup table elements together as configured. The pilot hole pattern is a group of four. Use four 1-1/8" wood screws per hub to install using #2 Phillips driver. The clips interlock to form the joining plate.







### Install modesty panel hooks.

Install two hooks for suspending the modesty panels. Each installs into pilot holes with two wood screws, each.



Modesty panel: steel frame with mesh fabric and hook-loop closures for wire management.



Hang the wire management modesty panel on two hooks.





Press SnapChase<sup>™</sup> wire management channel onto the preferred leg for wire management. SnapChase<sup>™</sup> fits any leg and is easily repositioned.